

Year(s)	Make	Model	Trim Level	Additional Info
1991-1998	VAUXHALL	ASTRA	F	1, 5, 6, 7, 8 = ON/DOWN For Vauxhall Vehicles with Resistive steering controls and ISOConnector
1993-1999	VAUXHALL	ASTRA	F CABRIOLET	1, 5, 6, 7, 8 = ON/DOWN For Vauxhall Vehicles with Resistive steering controls and ISOConnector
1998-2005	VAUXHALL	ASTRA	G	1, 5, 6, 7, 8 = ON/DOWN For Vauxhall Vehicles with Resistive steering controls and ISOConnector
2000-2006	VAUXHALL	ASTRA	G CABRIOLET	1, 5, 6, 7, 8 = ON/DOWN For Vauxhall Vehicles with Resistive steering controls and ISOConnector
2000-2006	VAUXHALL	ASTRA	G COUPE	1, 5, 6, 7, 8 = ON/DOWN For Vauxhall Vehicles with Resistive steering controls and ISOConnector
2010	VAUXHALL	ASTRA	H TWINTOP	1, 5, 6, 7, 8 = ON/DOWN For Vauxhall Vehicles with Resistive steering controls and ISOConnector
1994-1998	VAUXHALL	ASTRAVAN	F	1, 5, 6, 7, 8 = ON/DOWN For Vauxhall Vehicles with Resistive steering controls and ISOConnector
1998-2007	VAUXHALL	ASTRAVAN	G	1, 5, 6, 7, 8 = ON/DOWN For Vauxhall Vehicles with Resistive steering controls and ISOConnector
2001-2011	VAUXHALL	COMBO	C	1, 5, 6, 7, 8 = ON/DOWN For Vauxhall Vehicles with Resistive steering controls and ISOConnector
1993-2000	VAUXHALL	CORSA	B	1, 5, 6, 7, 8 = ON/DOWN For Vauxhall Vehicles with Resistive steering controls and ISOConnector

2000-2006	VAUXHALL	CORSA	C	1, 5, 6, 7, 8 = ON/DOWN For Vauxhall Vehicles with Resistive steering controls and ISOConnector
1994-2001	VAUXHALL	CORSAVAN	B	1, 5, 6, 7, 8 = ON/DOWN For Vauxhall Vehicles with Resistive steering controls and ISOConnector

2001-2007	VAUXHALL	CORSAVAN	C	1, 5, 6, 7, 8 = ON/DOWN For Vauxhall Vehicles with Resistive steering controls and ISOConnector
1994-2003	VAUXHALL	OMEGA	B	1, 5, 6, 7, 8 = ON/DOWN For Vauxhall Vehicles with Resistive steering controls and ISOConnector
2003-2008	VAUXHALL	SIGNUM	ALL TRIM LEVELS	1, 5, 6, 7, 8 = ON/DOWN For Vauxhall Vehicles with Resistive steering controls and ISOConnector
1997-1999	VAUXHALL	SINTRA	ALL TRIM LEVELS	1, 5, 6, 7, 8 = ON/DOWN For Vauxhall Vehicles with Resistive steering controls and ISOConnector
1995-2002	VAUXHALL	VECTRA	B	1, 5, 6, 7, 8 = ON/DOWN For Vauxhall Vehicles with Resistive steering controls and ISOConnector
2002-2009	VAUXHALL	VECTRA	C	1, 5, 6, 7, 8 = ON/DOWN For Vauxhall Vehicles with Resistive steering controls and ISOConnector
1999-2005	VAUXHALL	ZAFIRA	A	1, 5, 6, 7, 8 = ON/DOWN For Vauxhall Vehicles with Resistive steering controls and ISOConnector
2001-2007	VAUXHALL	CORSAVAN	C	1, 5, 6, 7, 8 = ON/DOWN For Vauxhall Vehicles with Resistive steering controls and ISOConnector